CLEANING METHOD
IN TWO CLICKS







HOW TO CLEAN PMMA EXTRUDED & STANDARD CAST

To use



Clean soft cloth or sponge





Mild soap or detergent and lukewarm water or Altuglas® cleaner or anti-static cleaner (to prevent attracting dust)

To avoid

Gritty cloth



Window cleaning fluids, benzene, concentrated alcohol and solvents



Why?

Scratches (optical properties loss)

Crazing (micro cracks => lower protection)

HOW TO CLEAN ALTUGLAS® SHIELDUP



Clean soft cloth or sponge



Mild soap or detergent

Mild soap or detergent and lukewarm water or Altuglas® cleaner or an anti-static cleaner



NOT gritty cloth


Or window cleaning fluids or benzoyl or concentrated alcohol or solvents



For all material: Rinse and dry with a damp cloth or chamois



STAY SAFE



Please use the right cleaning method

Your Altuglas International team

